

**Compatible with:**

The Extension Plate can be attached to any mounting bracket or flat surface with the applicable screws enclosed - self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.

**This Extension Plate has pre-drilled holes for the ProClip and AMPS standard.**



**Warnings:**

Carefully read all instructions and review the images before attaching.

**Do not** attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this extension plate.



1. Press a screwdriver (Philips) firmly through the pre-drilled holes in the Extension Plate to open them up. Place the Extension Plate over the matching holes in your mounting bracket. Attach it by using the applicable screws enclosed - self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.



2. Attached the base plate from the Holders tilt swivel to the Extension Plate with the enclosed screws in the Holder packaging.



3. Attach your Holder onto the Extension Plate. (see separate instruction enclosed with the Holder)



4. The Extension Plate with holders and devices in place. The Devices shown in the picture are an Apple iPhone 3G and a TomTom XL navigation unit.