

Compatible with:

Volkswagen CC 2009 - 2010
Volkswagen Passat 2005 - 2010 (EU)
Volkswagen Passat 2006 - 2010 (US)
Volkswagen Passat CC 2009 - 2010



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the panel surrounding the gear shift and the edge of the console.



Press downwards on the right side of the ProClip so the angled edge hooks under the edge of the console.



Press the right side of the ProClip towards the console side wall so the adhesive tape attaches.

The ProClip is in now place as shown in the overview picture above.