

Compatible with:

Ford Taurus 1996 - 1999
Mercury Sable 1996 - 1999

ONLY for models with Column shift.



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Press the angled edge on the lower part of the ProClip into the gap between the padded part of the dashboard and the panel frame surrounding the stereo.



2. Push the upper part of the ProClip forward towards the air vent.



3. Place your fingers on top of the ProClip and press down so the grooved edge on the ProClip snaps under the edge of the air vent frame surrounding the air vent. The ProClip is in place. Adjust the air vent to desired position.



4. The ProClip is in place.