

**Compatible with:**

Porsche 911-series 1999 - 2004  
Porsche Boxster series 1997 - 2004



**Warnings:**

Carefully read all instructions and review the images before attaching.

**Do not** attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Clean the surface at Pos. 1 with the enclosed alcohol pad. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip into the gap between the center console panels and the console edge.



2. Press firmly forward on the right side of the ProClip so the curved edge on the right side of the ProClip hooks behind the console edge by the carpet.



3. Make sure the curved edge on the ProClip has hooked properly behind the console edge by pressing it towards the console wall/edge.



4. The ProClip is in place.