

Compatible with:

Audi TT 1999 - 2006 (EU)
Audi TT 2000 - 2007 (US)



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Clean the surface with the enclosed alcohol pad. Peel off the adhesive tape cover on the ProClip.



2. Place the ProClip over the padded part.



3. Press down on top of the ProClip towards the floor until the angled edge on the left side of the Proclip under the padded edge.



4. The ProClip is in place.