

Compatible with:

Mini Cooper 2001 - 2006
Mini Cooper Convertible 2001 - 2007



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Open the glove compartment door. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the right side of the ProClip over the center console edge.



2. Place your hand on the right side of the ProClip face plate and press firmly leftwards, towards the steering wheel, so it hooks over the console edge.



3. Press firmly forward on the ProClip so the adhesive attaches properly. Close the glove compartment door.



4. The ProClip is in place.