

**Compatible with:**

Volkswagen Polo 2002 - 2009 (EU)



**Warnings:**

Carefully read all instructions and review the images before attaching.

**Do not** attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



Hook the upper part of the ProClip, with groove, behind the upper edge of the air vent housing.



Press upward/forward on the lower part of the ProClip so it hooks behind the lower edge of the air vent housing.



The ProClip is now in place as shown in the overview picture above.