

Item No. 853138 - ProClip Angled Mount, High



PROCLIP[®]
Installation Instructions

Compatible with:

Subaru Forester 2003 - 2008



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame to widen the gap. Peel off the cover of the adhesive tape on the ProClip.



Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.



Press the grooved edge on the upper part of the ProClip into the gap between the air vent panel frame and the dashboard. Press firmly forward until you see or hear/feel it snaps into place.

The ProClip is in now place as shown in the overview picture above.