

Item No. 853448 - ProClip Center Mount



Compatible with:

Pontiac Vibe 2003 - 2008
Toyota Matrix 2003 - 2004



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.



2. Push/Slide the ProClip all the way to the left, towards the air vent. Pull out the gap opener.



3. Press the gap opener into the gap between the dashboard and the center panel frame. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.



4. The ProClip is in place.