

**Item No. 854038 - ProClip Angled Mount**

x2  
GAP OPENER

A  
P

**ProClip**<sup>®</sup>  
mobile mounting solutions  
INSTALLATION INSTRUCTIONS

**Compatible with:**

Nissan Altima 2007 - 2012

**WARNING:**

Please hold the vehicle mount and holder over the place where the mount attaches to the dash **before** installing them to insure you like the location of the solution. Once installed and screwed together the products are **non-refundable**.

**Attention:**

Carefully read all instructions and review the images before installing this product.

**Do not** attach anything to the mount face plate until after installing the mount to the dashboard. Doing so makes it more difficult to install the mount to the dash and non-refundable since you have screwed into it.

To view an installation video, visit this link: <http://youtu.be/-8xYvKEGbh8>



1. Attention! This ProClip consists of two parts. Part 1 - ProClip attaching part (the smallest part) and Part 2 is the ProClip face plate. Press the thin end of one enclosed gap opener into the gap between the center console panel frame and the padded part of the dashboard. Press the second gap opener into the gap at the lower corner. Push both gap openers in until they stop, to widen the gap. Peel off the cover of the adhesive tape on Part 1.



2. Align the top of Part 1 with the panel line above the temperature controls to the left of the opened gap (notice the bold line in the photo) Or measure 5 1/8 down from the top of the seam.



3. Press the angled edges firmly into the gap and at the same time rotate Part 1 to the right until you see or hear/feel it clip into place behind the panel. Don't press the tape towards the console edge yet. First, slide Part 1 downwards until it stops. Then press Part 1 towards the console edge so the adhesive tape attaches. Pull out the gap openers.



4. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open the holes. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Do not attach the tape to the center console panel frame yet. First, screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip to the right with your thumb for optimal adjustment of the mount. Hold it in that position and tighten the screws. The ProClip is in place.