

**Item No. 9UOB00104 - TomTom car kit for iPhone
for in-car installation**

ProClip®
Installation Instructions

Compatible with:

Apple Car kit for iPhone by TomTom | Apple iPhone 2nd Generation (3G) | Apple iPhone 3G | Apple iPhone 3GS | Apple iPhone 3rd Generation (3G) | Apple iPhone 3rd Generation (3GS) | Apple iPhone 4/4S used with a Case | Apple iPhone TomTom CarKit | AT&T Apple iPhone 3G | AT&T Apple iPhone 3GS | AT&T Apple iPhone 4/4S WITHOUT Cases | TomTom Car kit for iPhone



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Place the 4-hole mounting plate on the back of the car kit over the matching holes in your mounting bracket (demo ProClip mount shown in picture) Attach the plate by using the self-tapping screws enclosed. To easier access the holes simply rotate the car kit to the applicable position.



2. To place the iPhone in the car kit, slide the iPhone down onto the bottom connector and then push forward on the top part of the iPhone so the top support arm hooks over the iPhone.



3. The iPhone in place in the car kit. The iPhone can be used in a vertical or horizontal position simply by rotating the car kit.



4. To remove the iPhone from the car kit, push against the top support arm to release the iPhone. Then pull the iPhone up and away from the car kit connector. **DO NOT** pull the iPhone towards you until after it has been released from the bottom connector. If you do the connector will break.

Please refer to the TomTom Car Kit specific manual in the box to set up your car kit to work with the iPhone.