

Item No. 853508 - ProClip Angled Mount, High



Compatible with:

Audi A6 2004 - 2009 (EU)
Audi A6 2005 - 2009 (US)
Audi A6 Avant 2004 - 2009 (EU)
Audi A6 Avant 2005 - 2009 (US)
Audi Allroad 2006 - 2009 (EU)
Audi S6 2004 - 2009 (EU)

Audi S6 2005 - 2009 (US)



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Place the grooved edge of the ProClip into the opener below the gap opener.



2. Press forwards on the lower part of the ProClip.



3. Press forwards on the upper part of the ProClip. Press until you hear/feel it snaps into place. Pull out the gap opener.



4. The ProClip is in place.