

Compatible with:

This instruction applies for all types of the Standard Holders, even if the design of your holder is different from the pictures shown below.



Warnings:

Carefully read all instructions and review the images before attaching.

The ProClip holder/mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Place the holder over the matching holes in your mounting bracket.
(ProClip Vehicle Mount shown in picture)



2. Attach the holder by using the self-tapping screws.
Note: the machine screws with nuts are for mounts made of metal with large holes.



3. The holder in place on the mount.



4. Slide the device down into the Holder.

To remove the device from the holder: slide it up and out. (iPhone shown in picture)