

Compatible with:

Position your device higher or lower on the mount.



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1.
Press a screwdriver (Philips) firmly through the pre-drilled holes in the Extension Plate to open them up. (If they are closed)
Place the Extension Plate in your hand so the three center lined holes are towards the top and then place the Extension Plate onto the ProClip so the holes match, then screw the Plate to the ProClip using the enclosed screws.



2.
The Extension Plate in place.



3.
When properly attached, you can attach holders etc. to the extension plate e.g. a cell phone holder as shown in the picture. Place the cell phone holder onto the Vertical Extension Plate so the holes match, then screw the holder to the Extension Plate using the enclosed screws.



4.
The Extension Plate is now in place as shown here (with a Nokia Phone attached to it) and in the overview picture above.