

Compatible with:

Inner dimensions: 31 x 50 x 14 mm / 1.2 x 2 x 0.55 inches. Outer dimensions: 50 x 50 x 16 mm / 2 x 2 x 0.6 inches.



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Place the Button & Clip Holder over the matching holes in the ProClip Vehicle Mount



2. Attach the Button and Clip Holder by using the self tapping screws enclosed.



3. The Button & Clip Holder is now in place.



4. Slide your device down into the Holder.