

Item No. 848636 - Padded Adjustable Holder with Tilt Swivel

ProClip®
Installation Instructions

Compatible with:

This Holder was originally designed with the Apple iPod in mind, using a skin or case. But it also fits other thicker devices with a skin or case e.g. Smart phones and PDAs etc. The Holder will adjust from a width of 2.3 inches (63mm) to 3.3 inches (85mm). The buttons and ports on the side of these devices may be covered up and the fit may not be a 100%.



Warnings:

Carefully read all instructions and review the images before attaching.


Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1.
To adjust the holder to your device:
Loosen the screws on the back side of the holder, so the sides of the holders can be adjusted. Place the unit in the holder and press the sides together so the unit is firmly in place. Screw on the screws on the back side of the holder.



2.
To install the holder:
Unscrew the screw in the center of the Holder and remove the Holder from the Tilt Swivel base plate.
Place the Tilt Swivel base plate over the matching holes in your mounting bracket (demo ProClip mount shown in picture) Attach the base plate by using the applicable screws enclosed – self-tapping screws if the mount has small holes or machine



3.
Place the Holder onto the Tilt Swivel base plate and attach it with the center screw. This screw also controls the pivot, tighter for a firm hold and loose for more (easier) movement/angling of the mounting plate.



4.
The holder in place.
Slide the device down into the Holder.
To remove the device from the Holder, slide it up and out.