

Item No. 511015A - Small Adjustable Holder with Tilt Swivel for smaller devices with or without a skin

ProClip®
Installation Instructions

Compatible with:

ProClip Other Holders

This Adjustable Holder is designed to hold smaller devices used with a skin case, but will also hold devices without a skin case. The buttons and ports may be covered up and the fit may not be a 100%, but it will still be a very good and convenient to use. The Holder will adjust from a width of 1.9 inches (48 mm) to 2.48 inches (63mm).



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1.
To fit the holder to your device: Loosen the left and right screws in the holder to release the sides. Pull the holder sides apart to widen the holder. Place the device in the holder and press the sides together so the device is held in place. Carefully remove the device without changing the position of the holder sides. Tighten the left and right screws in the holder in order to lock the sides into the correct position, suitable for your device.



2.
To install the holder: Unscrew the screw in the center of the Holder and remove the Holder from the Tilt Swivel base plate.



3.
Place the Tilt Swivel base plate over the matching holes in your mounting bracket (demo ProClip mount shown in picture) Attach the base plate by using the applicable screws enclosed – self-tapping screws if the mount has small holes or machine screws with nuts if the mount is made of metal and has large holes.
Place the Holder onto the Tilt Swivel base plate and attach it with the center screw. This screw also controls the pivot, tighter for a firm hold and loose for more (easier) movement/angling of the Holder.



4.
Slide the device down into the Holder. To remove the device from the Holder, slide it up and out.